

**ASSEMBLY INSTRUCTIONS:**

1. PLACE THE TUBE (D) ONTO THE COMPONENT POLE (E) AND TURN TO TIGHTEN
2. PLACE THE TUBE (C) ONTO THE COMPONENT POLE (D) AND TURN TO TIGHTEN
3. PLACE THE TUBE (B) ONTO THE COMPONENT POLE (C) AND TURN TO TIGHTEN
4. INSERT THE COMPONENT POLE (B) INTO THE LAMP BASE (A)
5. ADJUST THE DIRECTION, USE THE PROVIDED SCREWDRIVER (F) TO TIGHTEN THE INCLUDED SCREWS (G) TO HOLD THE COMPONENT POLE (B) AND THE LAMP BASE (A)
6. PLACE SHADE (I) ONTO THE SOCKET (H) AND TIGHTEN SCREW COLLAR RING (J) TO HOLD IT IN PLACE

**CLEANING:**

DO NOT USE POLISH OR CLEANING PRODUCTS ON YOUR LAMP. TO CLEAN USE A SOFT DRY CLOTH.

**WARNING:**

THIS PORTABLE LAMP HAS A POLARIZED PLUG, MEANING ONE BLADE IS WIDER THAN THE OTHER. AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY INTO THE OUTLET, REVERSE THE PLUG AND TRY AGAIN. IF IT WILL NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED.

