

Part # LS-LED PLANK XX

13-1206

PARTS



A



B



C

1**2****CAUTION**

For indoor use only. This is not a toy. Keep out of reach of children and animals. Place on flat surface and away from flammable materials. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas.