

Ozzy Ceiling Lamp


Part # LS-L-OSC CLG XX

15-0323


WARNING

Make sure main power supply is turned off at circuit breaker or fuse box before attempting any wiring project!
 Consult an electrician to ensure proper installation.

Parts



A



B



x2
C



x2
D







x3
E



x2
F
(not included)



x5
G
(not included)



CAUTION

For indoor use only. Keep out of reach of children and animals. Turn off power at main supply during installation. Never operate this appliance if it has a damaged cord, plug or cable. Keep cord away from heated and/or damp areas. Use only the included parts.