

Winston Chair

Part # CH-WINSTON XX

150720

PARTS



A



B



C



x1
6X30mm

F




x4
6X45mm

G




L

1




80%
tighten

2



80%
tighten

3



100%
tighten

4

