


# LAMP ASSEMBLY INSTRUCTIONS

1. Unpack all parts from cartons carefully.
2. Screw one lamp pole (B) onto the base (A) tightly, be careful not to twist the power cord.
3. Screw a lamp pole (C) onto the lamp pole (B) tightly.
4. Screw a lamp pole (D) onto the lamp pole (C) tightly.
5. Screw a lamp socket (E) onto the lamp pole (D) tightly.
6. Place shade (F) into socket (E) and tighten with socket ring (G).
7. Install bulb (H) into socket. (BULB NOT INCLUDED.)
8. ENSURE ALL CONNECTIONS ARE FULLY TIGHTENED BEFORE USE



## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

## INSTRUCTIONS DE MONTAGE DE LA LAMPE

1. Déballer soigneusement toutes les pièces des cartons.
2. Vis un poteau de lampe (B) sur la base (A) étroitement, veillez à ne pas tordre le cordon d'alimentation.
3. Visser un poteau de lampe (C) sur le poteau de lampe (B) étroitement.
4. Visser un poteau de lampe (D) sur le poteau de lampe (C) étroitement.
5. Vis screw une prise de lampe (E) sur le poteau de lampe (D) étroitement.
6. Place l'ombre (F) dans la prise (E) et serrer avec l'anneau de prise (G).
7. Installer l'ampoule (H) dans la prise. (BULB NON INCLUS.)
8. ASSUREZ-VOUS QUE TOUTES LES CONNEXIONS SONT ENTIÈREMENT RESSERRÉES AVANT UTILISATION

## INSTRUCTIONS DE SÉCURITÉ IMPORTANTES

CETTE LAMPE PORTATIVE A UNE PRISE DE COURANT POLARISÉE (UNE LAME EST PLUS LARGE QUE L'AUTRE) COMME A LA CARACTÉRISTIQUE POUR RÉDUIRE LE RISQUE DE DÉCHARGE ÉLECTRIQUE CETTE PRISE DE COURANT IRA DANS UNE ISSUE POLARISÉE SEULEMENT UNE VOIE. SI LA PRISE DE COURANT NE VA PAS COMPLÈTEMENT DANS L'ISSUE, INVERSEZ LA PRISE DE COURANT. S'IL NE VA PAS TOUJOURS, CONTACTEZ UN QUALIFIÉ ÉLECTRICIEN. N'UTILISEZ JAMAIS AVEC UNE CORDE D'EXTENSION À MOINS QUE LA PRISE DE COURANT NE PUISSE ÊTRE COMPLÈTEMENT INSÉRÉE. NE FAITES PAS CHANGEZ LA PRISE DE COURANT. ALTER THE PLUG.

