






Kari Accent Chair

Part # CHR-KARI XX+XX

20-0617

PARTS



Do not over tighten.
 Do not use power tools to assemble.